



096/01M - Important Notice!

096/01M - Important Notice!

096/01M Internal Manual Linkage Adjustment Procedure

*** PLEASE NOTE ***

Whenever a valve body is installed into an 096 or an 01M Transmission, the internal manual valve linkage **MUST BE ADJUSTED** to sync up the manual valve with the Rooster comb and external linkage.

The procedure for making this adjustment is as follows:

1. Install the valve body as usual.
2. Place the linkage into the park position.
3. Loosen the small adjusting bolt between the manual valve link and the rooster comb so that the adjusting arm will move freely.
4. Gently push the manual valve into the bore.
5. While holding gentle pressure on the manual valve toward the bore, tighten the adjustment bolt.

The manual valve only has to be out of adjustment a slight bit to encounter low pressure, delays into drive or delays into reverse.

If you have any questions concerning this procedure, please feel free to contact **VBX** directly at 1-866-2GET-**VBX**.

"We Build Them So You Don't Have To."